





Standing Seam Backer Rod

To release the paper from the adhesive on the standing seam backer rod, begin by gently lifting one corner of the paper to create a small gap between the paper and the tape. If this method is ineffective, try moving the backer rod up and down to create an air gap between the paper and the adhesive.

See illustration below.



The release paper is slippery and should be removed from the work area immediately.